

13.6. Shortcuts

The following shortcuts are available:

| | | |
|---------------------------------|---|------------|
| Page up/down | Zoom in/out | |
| Arrow up/down/left/right | Pan window | |
| z | Zoom extents or zoom to arrow or object | |
| w | Zoom window | |
| Ctrl + e | Zoom extents | |
| g | Show/hide grid | 3D Design |
| Space | Swap grid plane at cursor position | 3D Design |
| Shift + s | Toggle "Stay on Grid" | 3D Design |
| l | Select last created object | |
| Ctrl + r | Repeat last action | |
| Ctrl + Shift + a | Search action | |
| Ctrl + z | Undo | |
| Ctrl + Shift + z | Redo | |
| Ctrl + v | Paste selections from clipboard | |
| Ctrl + a | Select all visible objects | |
| Ctrl + s | Save project | |
| Ctrl + n | New project | |
| Ctrl + o | Open project | |
| Ctrl + q | Exit project | |
| Ctrl + g | Export Gerber file | 2D Design |
| Ctrl + wheel | Next/Previous animation frame | 3D Results |
| F[1,3,4] | Recall selection | |

After selection:

| | |
|--------------------------|------------------------------|
| Esc | Deselect all |
| Backspace | Deselect last |
| Shift + Backspace | Deselect first |
| Del | Delete selection |
| o | Open Object |
| Ctrl + c | Copy Selections to clipboard |
| Ctrl + x | Move Selections to clipboard |
| Ctrl + F[1,3,4] | Append selection |
| Shift + F[1,3,4] | Store selection |

After arrow input:

| | | |
|----------|--------------------|-----------|
| w | Zoom window | |
| p | Select overlapping | 2D Design |
| e | Select enclosed | 2D Design |
| m | Negate arrow | |
| + | Concat arrow | |
| / | Subdivide Arrow | 2D Design |
| * | Scale Arrow | 2D Design |

More shortcuts are available for some operations and displayed with balloons while pointing on the respective buttons.